

3580-421
0212
IMPORTANT : REBATE KITS **SUIT** 30mm and 38mm BACKSETS ONLY.

All Lockwood 3580 Series Short Backset Rebate Mortice Lock Kits are to be mounted in accordance with this instruction and in conjunction with the standard instructions supplied with the LOCK.

MORTICE INSTRUCTIONS

1. Place **LOCK** instruction template on door. Mark and drill lock mortice to desired backset depth.
2. Ease out mortice where necessary.
3. Place lock through **SPACER** and insert lock in mortice, scribe around Spacer for size of recess. Remove lock from mortice and chisel recess to receive spacer. Coverplate must be flush with protruding edge of door.

MOUNTING STRIKE

1. Mark out door frame for strike.
2. Mortice door frame for strike.
NB :Strike to be flush with face of frame. Bolt recess to be 15mm deep in door frame.

ELECTRIC REBATE

Counterbore 25mm Dia hole x 2mm deep (max) and drill 19mm Dia hole, 78mm below strike centre line.

3. Insert Magnet in hole.

